

HÔMMY

MÁY SẤY TÓC

KF-3130



HƯỚNG DẪN SỬ DỤNG

KF-3130

Vui lòng đọc kỹ hướng dẫn sử dụng trước khi dùng sản phẩm.

HƯỚNG DẪN SỬ DỤNG

KF-3130

THÔNG SỐ KỸ THUẬT

- Model: KF-3130
- Công suất: 2000-2200W
- Nguồn điện: 220-240V, 50/60Hz

HƯỚNG DẪN AN TOÀN QUAN TRỌNG

Khi sử dụng thiết bị điện, đặc biệt là khi có mặt trẻ em, phải luôn tuân thủ các biện pháp phòng ngừa an toàn cơ bản, bao gồm những điều sau:

GIỮ TRÁNH KHỎI NƯỚC, NGUY HIỂM:

Như với hầu hết các thiết bị điện, các bộ phận điện vẫn mang điện ngay cả khi công tắc tắt.

Để giảm nguy cơ tử vong do điện giật:

1. Luôn "rút phích cắm" ngay sau khi sử dụng.
2. KHÔNG sử dụng trong khi tắm.
3. KHÔNG đặt hoặc cất giữ thiết bị này ở nơi có thể rơi hoặc kéo vào bồn tắm hoặc bồn rửa.
4. KHÔNG đặt hoặc thả vào nước hoặc chất lỏng khác.
5. Nếu thiết bị rơi vào nước, hãy "rút phích cắm" ngay lập tức. KHÔNG thò tay vào nước.

MỘT SỐ BIỆN PHÁP AN TOÀN

Để giảm nguy cơ bỏng, điện giật, hỏa hoạn hoặc thương tích cho con người:

1. Không được để thiết bị mà không được giám sát khi đang cắm điện.
2. Cần giám sát chặt chẽ khi thiết bị này được sử dụng bởi, trên hoặc gần trẻ em hoặc cá nhân với một số bệnh khuyết tật.
3. Chỉ sử dụng thiết bị này cho mục đích sử dụng như được mô tả trong sách hướng dẫn này. Không sử dụng các phần đính kèm không được nhà sản xuất khuyến nghị.
4. Không bao giờ vận hành thiết bị này nếu nó có dây hoặc phích cắm bị hỏng, nếu nó không hoạt động bình thường, hoặc nếu nó bị hỏng hoặc bị rơi vào nước.
5. Giữ dây khỏi bề mặt lò sưởi. Không quấn dây xung quanh thiết bị.
6. Không bao giờ sử dụng trong khi ngủ.
7. Không bao giờ làm rơi hoặc chèn bất kỳ đối tượng nào vào bất kỳ lỗ nào.
8. Không sử dụng ngoài trời hoặc hoạt động ở nơi đang sử dụng các sản phẩm bình xịt (dạng xịt) hoặc nơi đang sử dụng oxy.
9. Không bao giờ chặn các lỗ thoát khí của thiết bị hoặc đặt thiết bị trên bề mặt 50ft, chẳng hạn như giường hoặc ghế dài, nơi lỗ thoát khí có thể bị chặn. Giữ cho các lỗ thoát khí không có xơ vải và những thứ tương tự.
10. KHÔNG hướng luồng khí nóng vào mắt hoặc các khu vực nhạy cảm với nhiệt khác.
11. phụ kiện (khi được trang bị) có thể bị nóng trong quá trình sử dụng. Để chúng nguội trước khi xử lý.
12. KHÔNG đặt thiết bị trên bất kỳ bề mặt nào khi thiết bị đang hoạt động.
13. Trong khi sử dụng thiết bị, hãy để tóc tránh xa cửa hút gió.
14. KHÔNG hoạt động với bộ chuyển đổi điện áp.
15. KHÔNG sử dụng dây nối với thiết bị này.

HƯỚNG DẪN SỬ DỤNG

KF-3130

HƯỚNG DẪN BẢO DƯỠNG NGƯỜI DÙNG

Thiết bị này được trang bị bộ điều chỉnh nhiệt có thể tắt nếu nhiệt độ vượt quá mức thoải mái do lỗ vào hoặc cửa thoát khí bị chặn một phần. Trong trường hợp thiết bị dừng trong khi sử dụng, hãy tắt công tắc và để thiết bị nguội đi, lúc đó bộ điều nhiệt sẽ tự động đặt lại. Trong quá trình sử dụng, không được chặn các lỗ thoát khí. Khi sử dụng thiết bị này gần nước (ví dụ: phòng tắm), nên sử dụng ổ cắm điện được bảo vệ bởi Bộ ngắt mạch lỗi nối đất.

BẢO DƯỠNG

Thiết bị của bạn hầu như không cần bảo trì. Không cần bôi trơn. Giữ cho bề mặt được gia nhiệt sạch sẽ và không có bụi, chất bẩn và keo xít tóc. Nếu cần làm sạch, hãy ngắt kết nối thiết bị khỏi nguồn điện và lau bên ngoài bằng khăn ẩm. Nếu dây bị xoắn, hãy tháo xoắn trước khi sử dụng.

CẢNH BÁO: Nếu có bất kỳ sự cố nào xảy ra, không cố gắng tự sửa chữa. Thiết bị này không có bộ phận người dùng có thể bảo dưỡng.

BẢO QUẢN

Khi không sử dụng, “rút phích cắm”.

Để thiết bị nguội và cất xa tầm tay trẻ em ở nơi khô ráo, an toàn.

Không bao giờ quấn dây xung quanh thiết bị vì điều này sẽ khiến dây bị mòn sớm và đứt. Xử lý dây cẩn thận để có tuổi thọ cao hơn và tránh bị giật, uốn mạnh, xoắn hoặc căng dây, đặc biệt là ở các đầu cắm.

HÔMMY

MÁY SẤY TÓC

KF-3130

SPECIFICATIONS

- Model: KF-3130
- Capacity: 2000-2200W
- Voltage: 220-240V, 50/60Hz

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliance, especially when children are present, basic safety precautions should always be followed, including the following:

KEEP AWAY FROM WATER, DANGER:

As with most electrical appliances, electrical parts are electrically live even when the switch is off.

To reduce the risk of death by electric shock:

1. Always “unplug it” immediately after using.
2. Do not use while bathing.
3. Do not place or store this appliance where it can fall or be pulled into a tub or sink.
4. Do not place in or drop into water or other liquid.
5. If an appliance falls into water, “unplug it” immediately. Do not reach into the water.

WARNING:

To reduce the risk of burns, electrocution, fire or injury to persons:

1. An appliance should never be left unattended when plugged in.
2. Close supervision is necessary when this appliance is used by, on, or near children or individuals with certain disabilities.
3. Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
4. Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been damaged or dropped into water.
5. Keep the cord away from heater surfaces. Do not wrap the cord around the appliance.
6. Never use while sleeping.
7. Never drop or insert any object into any opening.
8. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
9. Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air opening may be blocked. Keep the air openings free of lint, and the like.
10. Do not direct hot air toward eyes or other heat sensitive areas.
11. Attachments (when furnished) may be hot during use. Allow them to cool before handling.
12. Do not place appliance on any surface while it is operating.
13. While using the appliance, keep your hair away from the air inlets.
14. Do not operate with a voltage converter.
15. Do not use an extension cord with this appliance.

USER MANUAL

KF-3130

SAVE THESE INSTRUCTIONS USER MAINTENANCE INSTRUCTIONS

This appliance is equipped with a thermostat that may cycle OFF if the temperature exceeds comfort level due to partially blocked air inlet or air outlet openings. In the event that the appliance stops during use, turn off the switched and allow the appliance to cool down, at which time the thermostat will automatically reset. During use, do not block the air openings. When using this appliance near water (e.g., bathrooms), the use of an Electrical outlet protected by a Ground Fault Circuit Interrupter is recommended.

MAINTENANCE

Your appliance is virtually maintenance free. No lubrication is needed. Keep heated surface clean and free of dust, dirt, and hair spray. If cleaning becomes necessary, disconnect the appliance from the power source and wipe the exterior with a damp cloth. If the cord becomes twister, untwist prior to use.

WARNING: If any malfunction occurs, do not attempt to repair it yourself. This appliance has no user-serviceable parts.

STORAGE

When not in use, “unplug it.”

Allow the appliance to cool and store out of reach of children in a safe, dry location. Never wrap the cord around the appliance since this will cause the cord t wear prematurely and break. Handle cord carefully for longer life and avoid jerking, bending sharply, twisting or straining cord, especially at plug connections.

HÔMMY

HAIR DRYER

KF-3130