

材质: 80g双铜纸
尺寸: 75x75mm

BLUETOOTH SPEAKER Rezo Wooden Box

User Manual

Thank you for purchasing Bluetooth Speaker Rezo Wooden Box. Please carefully read user guide in properly and keep this for further reference.

Packing list

1 pc speaker
1 pc Type-C charging cable
1 pc user manual

Product specifications:

Bluetooth version: V5.3 Working distance: 10m SNR: ≥90db Battery: 3.7V 1200mAh Playing time: about 2-4 hour Speaker Power: 4Q10W	Frequency response: 120Hz-20KHz Unit size: 251*140*109mm Unit weight: about 900g Charging: DC5V/2A Charging time: about 2-3 tiếng
-------------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------

① Power Button

Power On: Move the button to "ON" to power it on, the speaker will sound "ting ting".
Power off: Move the button to "OFF" to power it off, the speaker will sound "ting, ting, ting".

Bluetooth Connection

- Power on the speaker and have promptone, Bluetooth enters the pairing mode, the function indicator light flashes quickly on the front of the speaker.
- The first connection, turn on the mobilephone/laptop..., turn on Bluetooth, search for the Bluetooth code name "Rezo Wooden Box" and click; after a few seconds, you will hear the prompt tone "ting ting" of successful pairing and connection, the decide displays connected, and the function indicator light is always on.
- In subsequent use, as long as the device's bluetooth is turned on, it can be automatically connected.
- If you want to connect to another device, Long press"PAUSE" and hear the prompt tone to disconnect Bluetooth connection.

② USB slot:

It can decode and play MP3 format audio when put the USB card into the slot.

③ TF slot:

It can decode and play MP3 format audio when put TF card into the slot.

④ AUX line in slot:

Use the jack 3.5 head input through outside devices to play music.

⑤ Audio output.

Use earphones or headphones (jack 3.5) when speaker is connected to listen to music by them.

⑥ DC 5V slot:

Use the standard type-c charging cable for power charging, Charging with a DC5V~2A USB power adapter

⑦ "M"- Mode button:

Mode switch key Bluetooth/USB/TF/FM/INPUT

⑧ Pause/play button:

Short press to pause/play music.

⑨ Previous track/Volume down

Short press this button when playing music, the player will play the last track.
Long press to decrease the volume continuously.
Clock, alarm clock adjustment digital minus.

⑩ Next track/Volume up

Short press button when playing music, the player will play the last track;
Long press to increase volume continuously.
Clock, alarm clock adjustment digital plus.

⑪ ⏸ button:

- Press the key briefly to enter the clock mode: press one more time, "hour hand" flashes first, if you want to adjust the hour hand, press the ⏸ or ⏸ key to adjust the number.
- Press the ⏸ key again, "minute hand" flashes, adjust same as above.
- Press long time this key when you finish.
- Press and hold the ⏸ key to turn off the alarm clock setting, the screen dont appear symbol ⏸. Press and hold this key again to turn on he alarm clock setting, the screen appear symbol ⏸.

⑫ ⏰ button:

- Press the key briefly to enter the alarm mode: "hour hand" flashes first, if you want to adjust the hour hand, press adjust, press the ⏸ or ⏸ key to adjust the number.
- Press the ⏸ key again, "minute hand" flashes, adjust same as above.
- Press long time this key when you finish.
- Press and hold the ⏸ key to turn off the alarm clock setting, the screen dont appear symbol ⏸. Press and hold this key again to turn on he alarm clock setting, the screen appear symbol ⏸.

⑬ Charging indicator light:

Charging indicator light up red when charging, and turns off when fully charged.

Wireless charging sensing area:

Need to turn on the power supply first and charging the speaker to use this function, and then put the mobile on the charging receiving sensing area of the loudspeaker box, your phone will be charged.

⑭ The 12/24H system:

Press the ⏸, ⏸ simultaneously for 3 seconds to switch the 12h hoặc 24h system.

TWS

While at the same time open two devices and not connected in the bluetooth mode, press the "M" key for 2-3 seconds either of the speaker until hear the sound, now it is TWS mode, then can pair the mobile. Press " M " key about 3s to cancel TWS function .

FM mode

In FM mode, press long pause/play bottom to search station automatically, press again to stop searching. Then, press short "+", "-" to choose the FM station.
Note: In the FM mode, put in micro charging cable or AUX cable to increase the FM radio signal .

Telephone function

When calling, double short click pause bottom to answer, double long click to refuse, short press to hang up the call after connecting Press twice quickly pause button in bluetooth connection mode to call the latest person called.

Attentions:

- Do not use abrasive cleaners to clean this product.
- Do not allow this product to be heated, close to fire source or direct sunlight for a long time. It will easy to burn and damage the electronic components.
- Do not attempt to disassemble this product to make any modifications.
- Do not use this product in the rain.
- If you do not plan to use this product for a long time, please store it in a dry environment and charge the speaker at least once a month to prolong its life and avoid extreme temperatures and dust.
- If you saw smoke coming out of the machine or other improper phenomenon , please contact the retailer to solve the issue immediately.
- Do not throw the machine.
- If this speaker crash during use, you can press and hold the power button for 8 seconds to reset and shut down.
- USB card pls use FAT32 format.
- The speaker does not have an automatic shutdown function and will enter power saving mode if no buttons are pressed for 30 seconds. When Speaker enter saving mode, battery life can be 30 hours nearby.

Note!
In order to improve product performance, our products are constantly updated. It is no additional notice about technical issues and this manual is for reference only, please forgive.
Thank you for your purchase.

LOA BLUETOOTH Rezo Wooden Box

Hướng dẫn sử dụng

Cảm ơn bạn đã lựa chọn Loa Bluetooth Rezo Wooden Box. Vui lòng đọc kỹ hướng dẫn để sử dụng đúng cách và giữ lại để tham khảo thêm.

Bộ sản phẩm gồm

1 pc speaker
1 pc dây sạc Type-C
1 pc hướng dẫn sử dụng

Thông số kỹ thuật sản phẩm:

Phiên bản bluetooth: V5.3 Khoảng cách làm việc: 10m SNR: ≥90db Pin: 3.7V 1200mAh Thời gian phát nhạc: khoảng 2-4 tiếng (tùy âm lượng)	Công suất loa: 4Q/10W Tần số: 120Hz-20KHz Kích thước: 251*140*109mm Trong lượng: khoảng 900g Sạc: DC5V/2A Thời gian sạc: khoảng 2-3 tiếng
---------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------

① Núm nguồn

Bật nguồn: Di chuyển nút qua chữ "ON" để bật nguồn, loa sẽ vang lên "tinh tinh".
Tắt nguồn: Di chuyển nút qua chữ "OFF" để tắt nguồn, loa sẽ vang lên "tinh, tinh, tinh".

Kết nối Bluetooth

- Mở nguồn loa sẽ có âm báo nhắc, Bluetooth chuyển sang chế độ chờ ghép nối và đèn báo chức năng bluetooth ở phía trước loa sẽ nhấp nháy nhanh.
- Lần đầu tiên kết nối, bật điện thoại di động/ máy tính/..., bật Bluetooth, tìm kiếm tên Bluetooth "Rezo Wooden Box" và nhấp vào; sau vài giây, bạn sẽ nghe thấy âm báo nhắc ghép nối "tinh tinh" và kết nối thành công, thiết bị hiển thị được kết nối và đèn sẽ luôn sáng.
- Trong lần sử dụng tiếp theo, Loa có thể tự động kết nối khi Bluetooth của thiết bị mà được kết nối gần nhất đang mở.
- Nếu muốn kết nối với thiết bị khác, nhấn giữ nút tạm dừng và sẽ có âm thanh vang lên để ngắt kết nối bluetooth với thiết bị trước.

② Khe cắm USB:

Nó có thể giải mã và phát âm thanh định dạng MP3 khi đặt thẻ USB vào khe cắm.

③ Khe cắm TF:

Nó có thể giải mã và phát âm thanh định dạng MP3 khi đưa thẻ TF vào khe cắm.

④ Khe cắm AUX:

Sử dụng đầu jack 3.5 để có thể kết nối thiết bị bên ngoài để nghe nhạc qua loa.

⑤ Đầu ra âm thanh:

Sử dụng tai nghe dây hoặc tai nghe chụp tai (jack 3.5) khi mà loa được kết nối để nghe nhạc thông qua tai nghe đó.

⑥ Khe cắm DC 5V:

Sử dụng cáp sạc Type-c tiêu chuẩn để sạc điện, sạc loa bằng bộ chuyển đổi USB DC-5V - 2A

⑦ Núm M chuyển chế độ kết nối:

Phím chuyển đổi chế độ Bluetooth/USB/TF/FM/INPUT.

⑧ Núm tạm dừng/phát:

Nhấn nhanh nút này để tạm dừng hoặc phát nhạc.

⑨ Phát bài nhạc trước đó /Giảm âm lượng

Nhấn nhanh nút này khi phát nhạc, loa sẽ phát lại bài hát trước đó. Nhấn và giữ để giảm âm lượng.
Ở chế độ đồng hồ và báo thức, nhấn và giữ để giảm số .

⑩ Phát bài nhạc tiếp theo/Tăng âm lượng

Nhấn nhanh nút khi phát nhạc, loa sẽ phát bài hát tiếp theo. Nhấn và giữ để tăng âm lượng liên tục.
Ở chế độ đồng hồ và báo thức, nhấn và giữ để tăng số.

⑪ Núm đồng hồ

- Nhấn nhanh phím để vào chế độ đồng hồ: Nhấn thêm một lần nữa thì kim giờ nhấp nháy, nếu muốn điều chỉnh kim giờ, ở đây nhấn nút tăng hoặc giảm âm lượng để điều chỉnh số.
- Nhấn phím đồng hồ thêm lần nữa kim phút nhấp nháy, điều chỉnh tương tự như trên.
- Nhấn và giữ nút này khi điều chỉnh xong.
- Nhấn và giữ nút này khi điều chỉnh xong.
Chú ý: Đồng hồ vẫn tự hoạt động khi tắt nguồn loa trừ trường hợp loa hết pin.

⑫ Núm báo thức

- Nhấn nhanh phím để vào chế độ đồng hồ báo thức: kim giờ nhấp nháy trước, nếu muốn điều chỉnh kim giờ, ở đây nhấn nút tăng hoặc giảm âm lượng để điều chỉnh số.
- Nhấn phím báo thức thêm lần nữa kim phút nhấp nháy, điều chỉnh tương tự như trên.
- Nhấn và giữ nút này khi điều chỉnh xong.
- Bấm tiếp và giữ phím này để tắt cài đặt đồng hồ báo thức, màn hình sẽ không xuất hiện kí hiệu đồng hồ ⏰ nữa. Nhấn và giữ thêm lần nữa để bật lại chế độ báo thức này, lúc này màn hình sẽ xuất hiện lại kí hiệu đồng hồ ⏰.

⑬ Đèn báo sạc

Đèn báo sạc sáng màu đỏ khi sạc và tắt khi được sạc đầy.

Vùng cảm biến sạc không dây:

Trước tiên bạn hãy bật nguồn lên và cắm sạc vào loa để có thể sử dụng chức năng này, sau đó để điện thoại di động vào vùng cảm biến trên hộp loa, điện thoại sẽ được sạc.

⑭ Chế độ 12/24h

Nhấn đồng thời nút ⏸, ⏸ trong 3 giây để chuyển chế độ 12h hoặc 24h.

TWS

Mở nguồn hai loa cùng một thời gian và ở trạng thái không kết nối bluetooth, nhấn phím "M" trong 2-3 giây cho một trong hai loa cho đến khi nghe thấy gọi ý, bây giờ là chế độ TWS, sau đó có thể ghép nối điện thoại di động. Nhấn phím "M" khoảng 3 giây để hủy chức năng TWS.

Chế độ FM

Ở chế độ FM, nhấn nhanh nút tạm dừng để tự động tìm đài phát, nhấn lần nữa để dừng tìm kiếm. Sau đó, ấn nhanh nút "+", "-" để chọn kênh FM.
Ghi chú: Ở chế độ FM, cắm cáp sạc micro hoặc cáp AUX để tăng tín hiệu đài FM.

Chức năng cho cuộc gọi

Khi có cuộc gọi đến, bấm nhanh hai lần nút tạm dừng để trả lời, bấm giữ 2 lần để từ chối, bấm nhanh để ngắt cuộc gọi sau khi kết nối. Ấn nhanh hai lần nút tạm dừng để gọi người mà gần nhất bạn gọi.

Chú ý:

- Không sử dụng chất tẩy rửa mài mòn để làm sạch sản phẩm.
- Không để Loa bị làm nóng, gần nguồn lửa hoặc tiếp xúc trực tiếp với ánh nắng mặt trời trong thời gian dài, nó sẽ dễ làm cháy và hỏng các linh kiện điện tử.
- Không cố gắng tháo rời sản phẩm này để thực hiện bất kỳ sửa đổi nào.
- Không sử dụng sản phẩm này dưới trời mưa.
- Nếu bạn không định sử dụng sản phẩm này trong một thời gian dài, vui lòng bảo quản nó ở nơi khô ráo và sạc loa ít nhất mỗi tháng một lần để kéo dài tuổi thọ của loa cũng như tránh nhiệt độ quá cao và bụi.
- Nếu nhìn thấy khói bốc ra từ máy hoặc hiện tượng bất thường khác vui lòng liên hệ với nhà bán lẻ để giải quyết vấn đề ngay lập tức.
- Không tác động mạnh hay để vật nặng lên loa.
- Nếu loa này bị lỗi trong quá trình sử dụng, bạn có thể nhấn và giữ nút nguồn trong 8 giây để đặt lại và tắt.
- Thẻ USB vui lòng sử dụng định dạng FAT32.
- Loa không có chức năng tự động tắt và sẽ chuyển sang chế độ tiết kiệm, thời lượng pin có thể gần 30 giờ.

Ghi chú!
Để nâng cao hiệu suất của sản phẩm, sản phẩm của chúng tôi được cập nhật liên tục. Nội dung có thể thay đổi mà không báo trước và sách hướng dẫn này chỉ mang tính chất tham khảo, mong bạn thứ lỗi. Cảm ơn bạn vì đã mua hàng.