

**W8**  
User manual

**CAUTION** 1

1. All the safety and operating instructions should be read before the appliance is operated.
2. All operating and user instructions should be followed.
3. The appliance should not be used near water — for example, near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool etc. It should not be exposed to dripping or splashing water, and no Objects filled with liquid, such as a vase, should be placed on the appliance.
4. Warning: To reduce the risk of fire of electric shock, do not expose this appliance to rain or moisture.
5. The appliance should be situated so that its location or position does not interfere with its proper ventilation. For example, the appliance should not be situated on a bed, sofa, rug, or similar surface that may block the ventilation openings; Or placed in a built-in installation, such as a closed bookcase or cabinet that may impede the flow of air through the ventilation openings.

**PACKAGE CONTENTS**

- |                  |     |
|------------------|-----|
| Speaker          | 1pc |
| Operation manual | 1pc |
| USB cable        | 1pc |



**BUTTON CONTROLS** 2



**Standby:**

Long press to Turn ON/OFF the unit.

**+ Next/Volume increase:**

• Short press to Increase the volume level.

- Under bluetooth and TF card mode, Long press to select the next song

**Pairing, Play/Pause:**

• under Bluetooth mode (without AUX IN and TF card in W8), long press enter in to pairing mode.

• long press to switch bluetooth and TF card mode, when TF card inserted.

• under Bluetooth and TF mode, short press to Pause/Play music under Bluetooth mode, when coming call, short press to answer and long press to reject the call.

**- Prev/Volume decrease:**

• Short press to Decrease the volume level.

- Under bluetooth and TF card mode, Long press to select the previous song

**Adjust the light color and brightness**

- short press to switch the display color,
- long press to adjust the brightness.

**F&D WARRANTY CARD**

**END-USER'S COPY**  
WARRANTY REGISTRATION CERTIFICATE

Mr./Mrs/Ms First Name: \_\_\_\_\_

Last Name: \_\_\_\_\_

Address: \_\_\_\_\_

Contact No.: \_\_\_\_\_

Product Name: \_\_\_\_\_

Model No.: \_\_\_\_\_

Serial No.: \_\_\_\_\_

Date Purchased: \_\_\_\_\_

Invoice No.: \_\_\_\_\_

Retail Outlet Where Purchased: \_\_\_\_\_

(Please print the name & address)

SECTION 1

**F&D WARRANTY CARD**

**DISTRIBUTOR'S COPY**  
WARRANTY REGISTRATION CERTIFICATE

Mr./Mrs/Ms First Name: \_\_\_\_\_

Last Name: \_\_\_\_\_

Address: \_\_\_\_\_

Contact No.: \_\_\_\_\_

Product Name: \_\_\_\_\_

Model No.: \_\_\_\_\_

Serial No.: \_\_\_\_\_

Date Purchased: \_\_\_\_\_

Invoice No.: \_\_\_\_\_

Retail Outlet Where Purchased: \_\_\_\_\_

(Please print the name & address)

SECTION 2

**WARRANTY TERMS & CONDITIONS**

The warranty will be effective only if the warranty card is completed and returned to the company within 14 days from the date of purchase. We guarantee the provision of free services of F&D product within the warranty period, from its date of purchase from our Authorised Dealer. The period and conditions of our warranty service are as follow:

1. The warranty covers services by our F&D Authorised Dealer. This warranty card together with the receipt must be presented when servicing is required. This warranty card is irreplaceable in the event of loss.

2. Repair services will be provided for defects arising from normal usage for the following period, commencing from the date of purchase from our F&D Authorised Dealer. (Parts would be replaced when necessary)

- A. Parts:..... 1 year
- B. Technical service free..... 1 year

3. Under the following circumstances, service and parts will be chargeable even within the warranty period:

A. Failure to present the warranty card and receipt when servicing is required.

Full particulars not clearly shown or alterations made against the actual information.

For e.g.: Alteration of the date of purchase, serial numbers-altered or removed.

B. This unit being tampered with, altered in any way by any unauthorised technicians or which has been subjected to misuse, negligence or accident. This guarantee does not cover damage occurring in transit by or from the customer.

C. The defect is caused by the attack of household pests, fire, lighting, natural disasters, pollution, abnormal voltage or the usage of generator.

Shenzhen Fenda Technology Co., Ltd.  
Add : Fenda Hi-Tech Park, Zhoushi Road, Shiyao, Baoan, Shenzhen, China  
P.C. : 518108 Http://www.fenda.com

**WARRANTY TERMS & CONDITIONS**

The warranty will be effective only if the warranty card is completed and returned to the company within 14 days from the date of purchase. We guarantee the provision of free services of F&D product within the warranty period, from its date of purchase from our Authorised Dealer. The period and conditions of our warranty service are as follow:

1. The warranty covers services by our F&D Authorised Dealer. This warranty card together with the receipt must be presented when servicing is required. This warranty card is irreplaceable in the event of loss.

2. Repair services will be provided for defects arising from normal usage for the following period, commencing from the date of purchase from our F&D Authorised Dealer. (Parts would be replaced when necessary)

- A. Parts:..... 1 year
- B. Technical service free..... 1 year

3. Under the following circumstances, service and parts will be chargeable even within the warranty period:

A. Failure to present the warranty card and receipt when servicing is required.

Full particulars not clearly shown or alterations made against the actual information.

For e.g.: Alteration of the date of purchase, serial numbers-altered or removed.

B. This unit being tampered with, altered in any way by any unauthorised technicians or which has been subjected to misuse, negligence or accident. This guarantee does not cover damage occurring in transit by or from the customer.

C. The defect is caused by the attack of household pests, fire, lighting, natural disasters, pollution, abnormal voltage or the usage of generator.

Shenzhen Fenda Technology Co., Ltd.  
Add : Fenda Hi-Tech Park, Zhoushi Road, Shiyao, Baoan, Shenzhen, China  
P.C. : 518108 Http://www.fenda.com


**Bluetooth mode**

- Turn ON the W8 & this will auto search the available Bluetooth device.
- Turn ON the "Bluetooth" function on your device (Mobile phone or smart devices) and search for "Fenda W8". Enter "0000" if your device asks for the PIN code to connect with W8.
- Once the device is paired, at next Turn ON, W8 will auto search the Bluetooth device & will connect to paired one automatically.
- If can't find the paired device, W8 will enter in to pairing mode automatically. In case W8 does not enter in to pairing mode, remove the TF card. Now long press of Play/pause key will enter in to pairing mode.

**Charging**

The unit has built in a rechargeable battery inside, before play the speaker, please follow up below step to charge the unit first.


1. Using the supplied USB cable to connect the MicroUSB jack, and another terminal connect with USB power like PC or other universal USB power.
2. During the charging, the red color LED indicator will turn on, and it will be off when the unit is fully charged.
3. Indicator: red color for charging, blue color for Bluetooth



**Specifications**

- Power Output: 4W
- Speaker unit: 2"
- Frequency Response: 80Hz-20KHz
- Power Input: 5V=1000mA
- Separation: ≥40dB
- S/N Ratio: ≥75dB
- Product dimension: W67\*D92\*H67mm
- Rechargeable Li-Ion Battery: 900mAh

**SHENZHEN FENDA TECHNOLOGY CO., LTD.**  
ADD: Fenda Hi-Tech Park, Zhoushi Road, Shiyao, Baoan, Shenzhen, China  
Tel: +86-755-27353888 (800 Line)  
Fax: +86-755-27353777  
P.C: 518108



注：此处虚线部分  
需要可扯开的虚线裁切

展开尺寸	350X120MM
成型尺寸	70X120MM
材质要求	80g书纸
印刷要求	单黑正反印刷
工艺要求	无处理
页码数(页)	折页

F&D 睿达科技		时 间	2017.04.10	订 单 号	
品 牌	F&D	公司型号	W3	客户型号	W3
版 本	A0	设计内容	说明书	料 号	
电 子 件		结 构 电 声		PLM文档编号	
设计者	江火维	标 准 化		项 目 经 理	
复 核		业 务		产 品 经 理	
				核 准	